

AIDAN (4867)

White Bone China



- 06/406 Dinner Plate 28cm
- 451/1 Accent Plate 23cm White with Medarion
- 451/2 Accent Plate 23cm Black with Medarion
- 04/405 Salad Plate
- 03/404 Side (Bread & Butter) Plate
- 19/427 Tea Pot
- 20/461 Coffee Server
- 14/419 Covered Vegetable / Casserole


We'd be pleased to advise you

Noritake


AIDAN (4867)

White Bone China

AIDAN (4867)



Dinner Plate
97320




Salad Plate
97311



B/B Plate
97212




Accent Plate
97316 / 4867001



Accent Plate
97316 / 4867002



Soup / Cereal
97207



Large Square Plate
97318



Small Square Plate
97317



Saucer Cup
93687S 93687C



A.D.Saucer A.D.Cup
97294S 97292C



Coffee Server
93653



Teapot
93623




Sugar w/Cover
93627



Creamer
93628




Covered Vegetable
93629




Gravy w/Tray(2pc)
93641



Salt/Pepper
936710




Oval Platter
97344




Round Platter
97305




Round Serving / Salad Bowl
97382



Large Square Bowl
97349



Rectangular Plate
97300



Butter/Relish Tray
93642



Care & Handling

Durability: Did you know that quality porcelain and bone china are actually the strongest ceramic dinnerware materials? It's true. They are fired at the highest temperatures and are made of the strongest ingredients. So you can use your finest china as often as you wish with as much confidence, or more, as your „everyday“ set of dishes.

Dishwasher: Noritake recently conducted extensive tests on several of its porcelain and bone china patterns and found that they are every bit as dishwasher safe as our everyday dinnerware. So feel free to use your „good china“ whenever you want to make an occasion special, or any time at all.

But keep this in mind about all of your dinnerware, glassware and tableware: treat them with the respect that high quality, beautifully crafted products of any kind deserve. Although very strong, porcelain and bone china are still breakable if abused.

* Don't overload your dishwasher with anything. Not only will you risk chipping or breakage, but your dinnerware won't get clean either because the water and detergent won't reach everything!

* Never use too much detergent.

* After the drying cycle, let your tableware cool down to room temperature before handling. The heat temporarily softens metal such as gold or platinum.

* Never put anything with metal (gold or platinum in the pattern or on the rim) in the microwave oven.

Detergent safe means Noritake technology has protected the delicate decorations from the effects of harsh detergent chemicals.