

Noritake

ODESSA PLATINUM (4875)

Noritake Dining Collection Bone China

Shape: Sheer White Bone China

Made by Noritake in Sri Lanka




Noritake

ODESSA PLATINUM (4875)

Noritake Dining Collection Bone China
Shape Sheer White Bone China

Sheer White Bone China



Care & Handling

Washing by hand: Noritake recommend hand washing of all their patterns. Avoid harsh scourers or abrasive pads. Even in water, the glazed surfaces can be scratched if rubbed against each other. So avoid putting too many items into the water at any one time.

Dishwasher: Dinnerware may be washed in a dishwasher. But keep this in mind about all of your dinnerware; treat them with the respect that high quality, beautifully crafted products of any kind deserve. Although very strong, porcelain ware and bone china are still breakable if abused.

** Don't overload your dishwasher with anything. Not only will you risk chipping or breakage, but your dinnerware won't get clean either because the water and detergent won't reach everything!*

** Never use too much detergent.*

** Use liquid detergent rather than powder or tablets.*

** Set temperature at around 55 to 60C and never over 65C.*

** After the drying cycle, let your tableware cool down to room temperature before handling. The heat temporarily softens metal such as gold or platinum.*

Microwave Oven: Never put anything with gold or platinum decorated china into microwave oven as it will permanently damage the precious metal.

Storage of Fine Dinnerware: To avoid scratching the surface, avoid sliding the china pieces over each other. Like diamonds cut diamonds, china's unglazed surface such as foot of plates or cups, can scratch china's surface. Protective pads or towels (including paper-towel) are helpful in avoiding scratching.